Typical Conditions

Lath

Key Way

Drill Holes
(Injection Sites)

Hole
Down to Lath to be Patched

Drilled Holes: 2" Away from Loose Crack, Every Other Lath

Around Patch: Every Lath

PLASTER MAGIC
FOR THE ULTIMATE PLASTER REPAIR®